


# PLAYMATE GENIE PC

---

## Owner's Manual

First Edition, December 2002



METALTEK  
455 Kitty Hawk Drive  
Morrisville, NC 27560  
Tel: 919-544-0344  
Fax: 919-544-1430  
[www.playmatetennismachines.com](http://www.playmatetennismachines.com)

# TABLE OF CONTENTS

INTRODUCTION .....	6
IMPORTANT SAFETY INSTRUCTIONS .....	7
ELECTRICAL REQUIREMENTS .....	8
GETTING STARTED .....	10
OPERATING INSTRUCTIONS .....	12
POWER .....	12
REMOTE CONTROL .....	12
TURN ON THE POCKET PC .....	13
PLACEMENT OF BALL MACHINE .....	13
BEGINNER MODE .....	15
SMART MODE .....	20
CHANGING THE DRILL .....	25
ADDING A SHOT TO THE DRILL .....	27
REMOVING A SHOT FROM THE DRILL .....	31
EDITING A SHOT .....	33
<b>CLASSIC MODE .....</b>	<b>39</b>
CHANGING BALL FEED RATE .....	44
CHANGING THE SEQUENCE .....	45
CHANGING DIRECTION .....	47
CHANGING SHOT HEIGHT .....	48
CHANGING SHOT SPEED .....	49
CHANGING SHOT SPIN .....	50
CHANGING SHOT DELAY .....	51
TURNING THE REMOTE ON AND OFF .....	52
CHANGING SPREAD ANGLE .....	53
USING RANDOM .....	55
<b>CHANGING MODES .....</b>	<b>56</b>
<b>END USER LICENSE AGREEMENT .....</b>	<b>60</b>

Dear Valued Customer,

*Congratulations on the purchase of your new Playmate Tennis Ball Machine. We have packed over 30 years of experience and dedication into the production of each and every ball machine to leave our high-tech facility in Raleigh, North Carolina.*

*It is our mission to build the most durable, dependable, and player-friendly machines. Quality is assured from the gear motors and pitching wheels, to the fully programmable control boxes and remote controls.*

*We hope that you enjoy your new ball machine as much as we enjoyed building it. We encourage your comments and suggestions on how we could better serve you in the future. Please feel free to contact us on our Consumer Connection Line at 1-800-776-6770.*

Sincerely,

Alfred F. Yarur  
President and CEO

## INTRODUCTION

The best way to improve your tennis game is to practice. That may sound like simple advice, but it's advice we take very seriously here at Metaltek. We believe that the best way to practice your game is to spend some quality time on the court with a ball machine. Only by utilizing a ball machine as a constant partner will you be able to repeatedly attack all the shots that make up your range as a player, whether that means strengthening your weaknesses or perfecting your strengths. A ball machine is your best choice of practice partner when it comes to developing a well-rounded game.

In this age of technological development, we have tried to find a happy balance between technical complexity and ease of operation. We have worked hard to maintain the clean, simple appearance of our design and the utility of our controls, while generating machines that can offer full game simulation and programmability. Even if you are still having trouble programming the VCR, we hope that our machines will present themselves without difficulty. After only a short while with this manual you should be able to have your new Playmate up and running, and be practicing the shots that you want to be practicing!

## IMPORTANT SAFETY INSTRUCTIONS

**WARNING!** To reduce the risk of electrical shock, fire, injury to persons, and other damage when using this product, please follow these basic safety precautions.

1. Read all instructions carefully before operating this machine.
2. To protect against the risk of electrical shock, never immerse any part of this machine in water or any other liquid.
3. Always use a grounded three-prong extension cord to supply power to this ball machine.
4. Close supervision is necessary when operating this machine near children.
5. Never walk in front of this machine when it is operating. Tennis balls leave the machine at high speeds and could cause serious injury.
6. Always stand to the side, or behind the machine when attempting to alter the settings of the various controls.
7. If it is necessary to free a jammed tennis ball, make sure that the machine is turned OFF and unplugged.
8. Always wear protective eyewear when attempting any repairs or adjustments on this machine.
9. Never attempt any repairs or adjustments on this machine when it is plugged in. Always turn the power switch OFF and unplug the power cord.
10. This machine is intended for pitching tennis balls only. Never attempt to use this machine with any other type of ball, or any foreign objects whatsoever.
11. Always make sure to turn this machine OFF when it is not in use.

---

## **ELECTRICAL REQUIREMENTS**

A heavy-duty power cord (not included) is recommended for use with the Playmate Tennis Machine. All machines should be plugged into a 120V 50/60 Hz outlet (220V 50/60 Hz outlet for overseas machines equipped with transformers). If you are using an extension cord of 100 feet long or less, we recommend that you use a 16 gauge or heavier extension cord that is grounded. For longer distances, a 14 gauge grounded extension cord is recommended.

This Page has intentionally been left blank.

## GETTING STARTED

Your new Playmate should have arrived securely packed. Make sure to inspect the machine for any damages that could have occurred during shipment. If machine is damaged please save all packing and box for inspection purposes. Inside the packing box, you should have found the PLAYMATE GENIE PC owner's manual, the POCKET PC with all its warranty and operating instructions, the Playmate warranty card, and the hand held on/off remote control. If any of these are missing, please notify Metaltek immediately. Your new Playmate should be ready for use in only a few minutes by completing the following easy steps.

**1. ASSEMBLING THE HANDLES** – The handles are reversed along the sides of the machine for compact shipment. To place them in their proper position, loosen the black triangular head screws until they are free. Swing the handles around 180 degrees until they are running parallel to each other behind the machine. Line up the holes and replace the triangular head screws, tightening until snug. DO NOT OVERTIGHTEN.

**2. SUPPLYING POWER** – Plug an extension cord into a grounded three-prong outlet of the proper ratings (see ELECTRICAL REQUIREMENTS), and attach the other end to the power cord on the right side of the machine.

**3. FILL THE HOPPER** – Depending on whether your machine has a large or small hopper, it will hold anywhere from 200 to 300 tennis balls. We recommend using pressureless tennis balls because they respond better for a longer period of time. Pressureless tennis balls are available from Metaltek by the gross.

**4. SET THE CONTROLS** – Your machine is just about ready for use. The last thing you will need to do is to familiarize yourself with your POCKET PC. Make sure to carefully read the OPERATING INSTRUCTIONS before attempting to use this machine.

**5. PLAYMATE PC SOFTWARE** - Your PC has been preloaded with the software program. The small blue card which is inserted at the top of your POCKET PC contains your software program.

**NOTE:** Take care not to damage this card since WITHOUT the card your system will not work.

**NOTE:** If possible, save the shipping box that your Playmate arrived in. Not only will it provide a safe place for long term storage, but will also provide proper protection if it is ever necessary to ship your Playmate in the future.

---

## OPERATING INSTRUCTIONS

---

### POWER

This switch is located on the right side of the ball machine and controls the power to the machine. When it is illuminated, power is being supplied.

### REMOTE CONTROL

The hand held remote control unit activates and deactivates the ball delivery system of the Playmate tennis machine. Push the button once to activate the delivery system, and once more to deactivate it. On ACE GENIE series or any directional machines if you hold the button down for 3 seconds it will reset the machine. The remote control is only active when the POWER switch is illuminated. The REMOTE CONTROL is automatically ON depending on the drills in the BEGINNER MODE and the SMART MODE. In the CLASSIC MODE you can turn it ON/OFF by tapping or pressing on the remote check box.

There is a total of three radio antennas located in the ball hopper. Make sure these antennas are pointing upward in order to increase the range of the remote control system.

**SAFETY PRECAUTION:** If the machine is turned ON and the REMOTE ON/OFF switch is in the OFF position the machine will begin to pitch balls.

### TURN ON THE POCKET PC

Follow the instructions on the Pocket PC to turn your unit on. The default mode for the Playmate PC software is BEGINNER MODE. Familiarize yourself with the BEGINNER MODE, SMART MODE, CLASSIC MODE and CHANGING MODES chapters.

### PLACEMENT OF BALL MACHINE


Place the machine at the center of the base line.

**NOTE:** Any control adjustments can be made while the machine is running provided the safety precautions are being followed.


# BEGINNER MODE

---


This Page has intentionally been left blank.




Turn on the Pocket PC. This is the desktop. Tap or press the **Start** button.




From the Start Menu, tap or press **PLAYMATE PC**.




The splash screen appears. Wait until the program starts or tap or press on the logo to immediately start PLAYMATE PC.



Tap or press on a Drill Category from the drop down list. For example, tap or press Teaching Drills.



Tap or press on the down arrow in the Categories combo box to select a Drill category.



Tap or press on a Drill from the list of drills in the Drill Category. For example, tap or press 2 Line High Approach Overhead.DRL.

This Page has intentionally been left blank.

**PARAMETERS**

1. Please select a Drill from the list below by tapping on the name of the desired Drill.

2. Press the SEND button.

Category:

2 Line Groundstroke Approach Volley Drill  
 3 Line Volley Overhead Drill


Now that you have selected a Drill, tap or press **SEND** to send the Drill to the ball machine.

**NOTE:** No changes can be made to the drills in the **BEGINNER MODE**. Simply choose a drill, press and send.


# SMART MODE




Turn on the Pocket PC. This is the desktop. Tap or press the Start button.




The splash screen appears. Wait until the program starts or tap or press on the logo to immediately start PLAYMATE PC.




From the Start Menu, tap or press PLAYMATE PC.




This is the main screen in the Smart Mode. Tap or Press on the down arrow.




Tap or press on the Open menu item to open a stored Drill.



Select a Folder that contains Drills. For example, select Teaching Drills.



Tap or press on the Folder drop down arrow to select a Drill Folder.



Tap or press on the name of the Drill that you want to open. For example, tap or press on 2 Line Volley Overhead.

## CHANGING THE DRILL

SEND **Flat Volley Overhead** **Flat Volley** **OH**

Shot	Delay	Dr
1 Flat Volley	1 1/2	2
2 Flat Volley	1 1/2	3
3 High Lob	1 1/2	5
4 High Lob	1 1/2	5

Add Shot

Shot Name: Flat Volley Delay: Dr: 5

Tap or press on the SEND button in order to send the Drill to the ball machine.

SEND **Flat Volley Overhead** **Flat Volley** **OH**

Shot	Delay	Dr
1 Flat Volley	1 1/2	3
2 Flat Volley	1 1/2	5
3 High Lob	1 1/2	5
4 High Lob	1 1/2	5

Add Shot Remove Shot

Shot Name: Flat Volley Delay: Dr: 5

The Smart Mode displays the shots in the Drill in the order that they are supposed to be fired. To change a shot, delay, or direction of a shot in the Drill, highlight the desired shot by tapping or pressing on it. For example, tap or press on the second row to highlight **Flat Volley** as shown.

SEND **Flat Volley Overhead** **Flat Volley** **OH**

Shot	Delay	Dr
1 Flat Volley	1 1/2	2
2 Flat Volley	1 1/2	5
3 High Lob	1 1/2	5
4 High Lob	1 1/2	5

Flat Volley  
High Approach  
High Lob  
Low Approach  
Offense Lob  
Flat Volley

Add Shot Remove Shot


Shot Name: Flat Volley Delay: Dr: 5

After highlighting a shot, a different shot can be selected by choosing a different shot in the **Shot Name** combo box towards the bottom of the screen.


**NOTE:** Both Personal and Teaching Drills have been pre-programmed in your PLAYMATE PC. You may use these DRILLS, CHANGE THEM and SAVE them with another name or ADD your own.

## ADDING A SHOT TO THE DRILL


A different delay can be chosen from the Delay combo box. This Delay represents the amount of time before the shot is supposed to be fired in the Drill.




Tap or press on the Add Shot button in order to add a shot to the end of the Drill.




A different direction can be chosen from the Direction combo box.




From the Add Shot Screen, tap or press on the Shot drop down arrow to select the type of Shot to add to the Drill.







Select the name of the Shot to Add to the Drill.



Select the direction where the Shot should be fired.



Select the amount of time in seconds before this Shot should be fired in the Drill.



Once you have selected the shot, delay, and direction, tap or press on the OK button to Add the Shot to the Drill. Tap or press on Cancel button if you do not want to Add the Shot to the Drill.

## REMOVING A SHOT FROM THE DRILL

Time Valley Overhead (8:44)

SEND SEQUENCE 1 1 1

Shot	Delay	Dr
1 Flat Volley	1 1/2	2
2 Flat Volley	1 1/2	5
3 High Lob	1 1/2	2
4 High Lob	1 1/2	2
5 Flat Volley	1 1/2	2

Add Shot Remove Shot

Shot Name Flat Volley Delay 1 1/2 Dr 5

As you can see, the new Shot was added to the end of the Drill.

Time Valley Overhead (8:44)

SEND SEQUENCE 1 1 1

Shot	Delay	Dr
1 Flat Volley	1 1/2	2
2 Flat Volley	1 1/2	5
3 High Lob	1 1/2	2
4 High Lob	1 1/2	5
5 Flat Volley	1 1/2	2

Add Shot Remove Shot

Shot Name Flat Volley Delay 1 1/2 Dr 2

Highlight the shot that you want to remove from the Drill by tapping or pressing on it.

Time Valley Overhead (8:44)

SEND SEQUENCE 1 1 1


Shot	Delay	Dr
1 Flat Volley	1 1/2	2
2 Flat Volley	1 1/2	5
3 High Lob	1 1/2	2
4 High Lob	1 1/2	5
5 Flat Volley	1 1/2	2

Add Shot Remove Shot


Shot Name Flat Volley Delay 1 1/2 Dr 2

Tap or press on the Remove Shot button in order to remove the highlighted shot from the Drill.

## EDITING A SHOT





Tap or press on the down arrow in order to bring up the menu.




Tap or press on the Editor... menu item.

As you can see, the highlighted shot has been removed from the Drill.







From the Editor screen, tap or press on the drop down arrow on the Shot combo box to select the shot that you want to edit.




Tap or press on the Height, Speed, or Spin knob in order to modify the Shot.




Tap or press on the name of the Shot that you want to edit. Shot that start with the character ' ' are factory default shots. They cannot be removed, but you can edit them.




Use the buttons to change the value of the Height and then press the OK button to accept the changes or press the X in the top right hand corner to cancel the changes.




Use the buttons to change the Speed value and then press the **OK** button to accept the changes or press the **X** in the top right hand corner to cancel the changes.



Tap or press on the **Save** button in order to save the current Height, Speed, or Spin changes.



Use the buttons to change the Spin value and then press the **OK** button to accept the changes or press the **X** in the top right hand corner to cancel the changes.




Tap or press on the **X** in the top right hand corner to exit the Editor.


# CLASSIC MODE

---


This Page has intentionally been left blank.




Turn on the Pocket PC. This is the desktop. Tap or press the Start button.




From the Start Menu, tap or press PLAYMATE PC.




The splash screen appears. Wait until the program starts or tap or press on the logo to immediately start PLAYMATE PC.



This is the Main View when using the Classic Mode. Tap or press on the down arrow.




Tap or press on the Open menu item.




Tap or press on the drop down arrow on the Folder combo box.


Select a folder that contains Drills. For example, tap or press on the Teaching Drills item in the drop down list.




Select a Drill from the list of Drills in the file list. For example, tap or press on 2 Line High Approach Overhead in the file list.




The top of the screen indicates the name of the current Drill. Tap or press on SEND to send the Drill to the ball machine.



## CHANGING BALL FEED RATE




Tap or press on the Ball Feed knob to adjust how frequently the balls are pitched overall.




Press on the +10 button to increase the Ball Feed by 10%, -10 button to decrease the Ball Feed by 10%, +1 button to increase the Ball Feed by 1%, and -1 button to decrease the Ball Feed by 1%. Press OK when done. To make no changes, press on the X in the top right corner.

## CHANGING THE SEQUENCE




Tap or press on the Sequence Position of the Sequence Position that you want to change. For example, tap or press on Sequence Position 1 to select a different Shot to fire first in the Drill.




Tap or press on the drop down arrow on the combo box in order to choose a different Shot to fire first in the Drill.

## CHANGING SHOT HEIGHT




Tap or press on the Height knob to adjust how high a Shot is pitched. For example, tap or press on the Height of Shot 1.




Press on the +10 button to increase the Height by 10%, -10 button to decrease the Height by 10%, +1 button to increase the Height by 1%, and -1 button to decrease the Height by 1%. Press OK when done. To make no changes, press on the X in the top right corner.

## CHANGING SHOT SPEED




Tap or press on the Speed knob to adjust how fast a Shot is pitched. For example, tap or press on the Speed knob for Shot 1 to adjust the speed for Shot 1.



Press on the +10 button to increase the Speed by 10%, -10 button to decrease the Speed by 10%, +1 button to increase the Speed by 1%, and -1 button to decrease the Speed by 1%. Press OK when done. To make no changes, press on the X in the top right corner.


## CHANGING SHOT DELAY

Tap or press on the **Spin** knob to adjust the topspin or backspin for a Shot. For example, tap or press on the Spin knob for Shot 1 to adjust the spin for Shot 1.




Tap or press on the **Delay** knob to slow down how soon a Shot is fired. For example, tap or press on the Delay knob for Shot 1 to delay how soon Shot 1 is fired.

Press on the **large forward** button to increase the topspin by 10%, **large reverse** button to increase the backspin by 10%, **small forward** button to increase the topspin by 1%, and **small reverse** button to increase the backspin by 1%. Press **OK** when done. To make no changes, press on the **X** in the top right corner.




Press on the **+10** button to increase the amount of Delay by 10%, **-10** button to decrease the amount of Delay by 10%, **+1** button to increase the amount of Delay by 1%, and **-1** button to decrease the amount of Delay by 1%. Press **OK** when done. To make no changes, press on the **X** in the top right corner.

## TURNING THE REMOTE ON AND OFF




Tap or press on the Remote check box to enable or disable the ball feed remote control. For example, tap or press on the Remote check box so that there is a check in the box. This means that you will have to use the remote control to start and stop the ball feed.

## CHANGING SPREAD ANGLE




Tap or press on the down arrow.




Tap or press on the Spread Angle menu item.


## USING RANDOM



Tap or press on the Random check box to enable or disable the random feature for the Drill. For example, tap or press on the Random check box so that there is a check in the box. In this Drill, either Shot 3 or Shot 5 will be fired at Random.




Tap or press on the Random check box to enable or disable the random direction feature for the Drill. For example, tap or press on the Random check box next to the Direction thumb wheel so that there is a check in the box. This means that the Shots in the Drill will be fired to random directions selected in the Drill. In this Drill, either Direction 2 or Direction 5 will be chosen at random.




Press on the +10 button to increase the amount of Spread Angle by 10%, -10 button to decrease the amount of Spread Angle by 10%, +1 button to increase the amount of Spread Angle by 1%, and -1 button to decrease the amount of Spread Angle by 1%. Press OK when done. To make no changes, press on the X in the top right corner.

# CHANGING MODES




Tap or press on the **down** arrow in order to bring up the menu.


Tap or press on the **down** arrow in order to bring up the menu.



Tap or press the **About** menu item.




Tap or press on the **down** arrow in order to bring up the **About** screen.




1. Please select a **Dr.** from the list below by tapping on the name of the desired **Dr.**
2. Press the **SEND** button.


Tap or press on the User Interface Mode drop down arrow in order to change the User Interface Mode.



Select the mode that you want to use from the drop down list.



Now that you have selected a new mode, tap or press on the X in the top right hand corner. Close the PLAYMATE PC program and start it again from the Start Menu. You are now using the desired User Interface Mode.



# END USER LICENSE AGREEMENT

## SOFTWARE END USER LICENSE AGREEMENT FOR PLAYMATE PC

### NOTICE TO USER:

THIS IS A CONTRACT. BY USING THIS SOFTWARE YOU ACCEPT ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT.

This Metaltek End User License Agreement accompanies the PLAYMATE PC product and related explanatory materials ("Software"). The term "Software" also shall include any upgrades, modified versions or updates of the Software licensed to you by Metaltek. Please read this Agreement carefully. At the end, you will be asked to accept this agreement. If you do not wish to accept this Agreement, you must decline this agreement, in which case you will not be able to use the Software.

Upon your acceptance of this Agreement, Metaltek grants to you a nonexclusive license to use the Software, provided that you agree to the following:

#### 1. Use of the Software.

You may install the Software on (1) hard disk or other storage device and make backup copies of the Software.

2. Copyright and Trademark Rights. The Software is owned by Metaltek and its suppliers, and its structure, organization and code are the valuable trade secrets of Metaltek and its suppliers. The Software also is protected by United States Copyright Law and International Treaty provisions. You may use trademarks only insofar as required to comply with Section 1 of this Agreement in accordance with accepted trademark practice, including identification of trademark owner's name. Such use of any trademark does not give you any rights of ownership in that trademark. Except as stated above, this Agreement does not grant you any intellectual property rights in the Software.

3. Restrictions. You agree not to modify, adapt, translate, reverse engineer, decompile, disassemble or otherwise attempt to discover the source code of the Software. You may not alter or modify in any way the program or create a new installer for the Software. The Software is licensed and distributed by Metaltek for controlling PLAYMATE ball machines.

4. No Warranty. The Software is being delivered to you AS IS and Metaltek makes no warranty as to its use or performance. METALTEK AND ITS SUPPLIERS DO NOT AND CANNOT WARRANT THE PERFORMANCE OR RESULTS YOU MAY OBTAIN BY USING THE SOFTWARE OR DOCUMENTATION. METALTEK AND ITS SUPPLIERS MAKE NO WARRANTIES, EXPRESS OR IMPLIED, AS TO NONINFRINGEMENT OF THIRD PARTY RIGHTS, MERCHANTABILITY, OR FITNESS FOR ANY PARTICULAR PURPOSE. IN NO EVENT WILL METALTEK OR ITS SUPPLIERS BE LIABLE TO YOU FOR ANY CONSE-

QUENTIAL, INCIDENTAL OR SPECIAL DAMAGES, INCLUDING ANY LOST PROFITS OR LOST SAVINGS, EVEN IF A METALTEK REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY THIRD PARTY. Some

states or jurisdictions do not allow the exclusion or limitation of incidental, consequential or special damages, or the exclusion of implied warranties or limitations on how long an implied warranty may last, so the above limitations may not apply to you.

5. Governing Law and General Provisions. This Agreement will be governed by the laws of the State of North Carolina, U.S.A., excluding the application of its conflicts of law rules. This Agreement will not be governed by the United Nations Convention on Contracts for the International Sale of Goods, the application of which is expressly excluded. If any part of this Agreement is found void and unenforceable, it will not affect the validity of the balance of the Agreement, which shall remain valid and enforceable according to its terms. You agree that the Software will not be shipped, transferred or exported into any country or used in any manner prohibited by the United States Export Administration Act or any other export laws, restrictions or regulations. This Agreement shall automatically terminate upon failure by you to comply with its terms. This Agreement may only be modified in writing signed by an authorized officer of Metaltek.

6. Notice to Government End Users. If this product is acquired under the terms of a GSA contract- Use, reproduction or disclosure is subject to the restrictions set forth in the applicable ADP Schedule contract; U.S. DoD contract- Use, duplication or disclosure by the Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of 252.227-7013; Civilian agency contract- Use, reproduction, or disclosure is subject to 52.227-19 (a) through (d) and restrictions set forth in the accompanying end user agreement.

Unpublished-rights reserved under the copyright laws of the United States.  
Metaltek, PO Box 30399, Raleigh, NC 27622.

YOUR ACCEPTANCE OF THE FOREGOING AGREEMENT WAS INDICATED BY YOUR USE OF THIS PRODUCT.